

Manufacturer	Model	System	Ecu name	Ecu name2	feature	FeatureID	Detail
Daewoo	Kalos	Brake System	ABS		Live Parameters	1	Number of trouble codes
Daewoo	Kalos	Brake System	ABS		Live Parameters	2	ABS: failure
Daewoo	Kalos	Brake System	ABS		Live Parameters	3	EBD fault detection
Daewoo	Kalos	Brake System	ABS		Live Parameters	4	TCS malfunction
Daewoo	Kalos	Brake System	ABS		Live Parameters	5	Valve relay error
Daewoo	Kalos	Brake System	ABS		Live Parameters	6	Battery voltage
Daewoo	Kalos	Brake System	ABS		Live Parameters	7	Wheel speed, left front
Daewoo	Kalos	Brake System	ABS		Live Parameters	8	Wheel speed, right front
Daewoo	Kalos	Brake System	ABS		Live Parameters	9	Wheel speed, left rear
Daewoo	Kalos	Brake System	ABS		Live Parameters	10	Wheel speed, right rear
Daewoo	Kalos	Brake System	ABS		Live Parameters	11	ABS warning lamp
Daewoo	Kalos	Brake System	ABS		Live Parameters	12	EBD warning lamp
Daewoo	Kalos	Brake System	ABS		Live Parameters	13	TCS warning lamp
Daewoo	Kalos	Brake System	ABS		Live Parameters	14	TCS off indicator
Daewoo	Kalos	Brake System	ABS		Live Parameters	15	TCS power switch
Daewoo	Kalos	Brake System	ABS		Live Parameters	16	Brake switch
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	1	Desired idle speed
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	2	Engine speed
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	3	MAP sensor
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	4	Throttle position
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	5	Intake air temperature
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	6	Engine coolant temperature at engine start.
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	7	Coolant temperature
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	8	IAC motor position
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	9	O2 sensor
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	10	O2 sensor heating
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	11	Fuel system status
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	12	O2-sensor rich/lean (bank 1 sensor 1)
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	13	Engine load
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	14	Short term fuel trim
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	15	Long term fuel trim
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	16	Linear EGR feedback
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	17	EGR - valve, duty cycle
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	18	Spark advance
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	19	Distance driven with MIL on (km)
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	20	Running time with Malfunction Indicator Lamp (MIL) ON
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	21	Injection time
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	22	Barometric pressure
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	23	Ignition, voltage
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	24	Air/fuel ratio
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	25	Calculated mass air flow value
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	26	Total number of misfires
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	27	Cylinder 1 History Misfire Counter
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	28	Cylinder 2 History Misfire Counter
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	29	Cylinder 3 History Misfire Counter
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	30	Cylinder 4 History Misfire Counter
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	31	Vehicle speed
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	32	Throttle position for idle
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	33	A/C pressure
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	34	A/C requested
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	35	A/C clutch
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	36	Fuel Pump Command
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	37	Closed Loop
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	38	O2 sensor ready (bank 1 sensor 1)
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	39	Knock sensor, present
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	40	Low Speed Fan
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	41	High Speed Fan
Daewoo	Kalos	Engine Petrol	1,4 DOHC General		Live Parameters	42	Torque converter clutch (TCC), engaged

Daewoo	Kalos	Engine Petrol	1,4 DOHC General	Live Parameters	43 Fuel level input
Daewoo	Kalos	Engine Petrol	1,4 DOHC General	Live Parameters	44 Fuel Level Output Circuit
Daewoo	Kalos	Engine Petrol	1,4 DOHC General	Live Parameters	45 Fuel trim cell
Daewoo	Kalos	Engine Petrol	1,4 DOHC General	Live Parameters	46 Engine Runtime
Daewoo	Kalos	Engine Petrol	1,4 DOHC General	Live Parameters	47 Intake air temperature at engine start
Daewoo	Kalos	Engine Petrol	1,4 DOHC General	Live Parameters	48 Purge control solenoid valve (duty)
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	1 Desired idle speed
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	2 Engine speed
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	3 MAP sensor
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	4 Throttle position
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	5 Intake air temperature
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	6 Engine coolant temperature at engine start.
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	7 Coolant temperature
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	8 IAC motor position
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	9 O2 sensor
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	10 O2 sensor heating
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	11 Fuel system status
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	12 O2-sensor rich/lean (bank 1 sensor 1)
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	13 Engine load
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	14 Short term fuel trim
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	15 Long term fuel trim
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	16 Linear EGR feedback
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	17 EGR - valve, duty cycle
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	18 Spark advance
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	19 Distance driven with MIL on (km)
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	20 Running time with Malfunction Indicator Lamp (MIL) ON
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	21 Injection time
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	22 Barometric pressure
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	23 Ignition, voltage
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	24 Air/fuel ratio
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	25 Calculated mass air flow value
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	26 Total number of misfires
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	27 Cylinder 1 History Misfire Counter
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	28 Cylinder 2 History Misfire Counter
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	29 Cylinder 3 History Misfire Counter
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	30 Cylinder 4 History Misfire Counter
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	31 Vehicle speed
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	32 Throttle position for idle
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	33 A/C pressure
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	34 A/C requested
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	35 A/C clutch
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	36 Fuel Pump Command
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	37 Closed Loop
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	38 O2 sensor ready (bank 1 sensor 1)
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	39 Knock sensor, present
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	40 Low Speed Fan
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	41 High Speed Fan
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	42 Torque converter clutch (TCC), engaged
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	43 Fuel level input
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	44 Fuel Level Output Circuit
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	45 Fuel trim cell
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	46 Engine Runtime
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	47 Intake air temperature at engine start
Daewoo	Kalos	Engine Petrol	1,4 SOHC General	Live Parameters	48 Purge control solenoid valve (duty)
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	1 Engine temperature
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	2 Intake air temperature
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	3 Throttle position
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	4 Battery voltage
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	5 Vehicle speed

Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	6 Engine speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	7 Barometric pressure
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	8 MAP sensor
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	9 MAF (Mass Air Flow)
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	10 Injection start
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	11 Injection time
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	12 Residual fuel adjust
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	13 Gear ratio (M/T)
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	14 Canister purge valve, duty cycle
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	15 Fuel tank level
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	16 Evaporator temperature
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	17 Motorized throttle idle actuator, actual value
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	18 Motorized throttle idle actuator, desired value
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	19 Engine status
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	20 Fuel pump relay
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	21 Engine full load
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	22 Idle switch
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	23 AC relay
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	24 Cooling fan low speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	25 Cooling fan high speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	26 Idle speed actuator duty cycle
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	27 Desired idle speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	28 Long term fuel part load
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	29 Long term fuel trim at idle
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	30 Short term fuel trim
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	31 Knock sensor
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	32 Octane of fuel
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	33 Closed loop fuel control
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO II	Live Parameters	34 Upstream O2 sensor
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	1 Engine temperature
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	2 Intake air temperature
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	3 Throttle position
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	4 Battery voltage
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	5 Vehicle speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	6 Engine speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	7 Barometric pressure
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	8 MAP sensor
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	9 MAF (Mass Air Flow)
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	10 Injection start
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	11 Injection time
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	12 Residual fuel adjust
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	13 Gear ratio (M/T)
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	14 Canister purge valve, duty cycle
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	15 EGR command
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	16 Fuel tank level
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	17 Motorized throttle idle actuator, actual value
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	18 Motorized throttle idle actuator, desired value
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	19 Engine status
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	20 Fuel pump relay
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	21 Engine full load
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	22 Idle switch
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	23 AC relay
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	24 Cooling fan low speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	25 Cooling fan high speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	26 Motorized throttle idle actuator duty
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	27 Desired idle speed
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	28 Long term fuel part load
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	29 Long term fuel trim at idle
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	30 Short term fuel trim

Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	31 Knock sensor
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	32 Octane of fuel
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	33 Wheel speed (hall)
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	34 Total distance last time DTC was stored
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	35 Closed loop fuel control
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	36 Upstream O2 sensor
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	37 Downstream O2 sensor
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	38 Closed loop fuel (adaptation factor)
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	39 Segment learn status
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	40 Segment learn cyl.1
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	41 Segment learn cyl.2
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	42 Segment learn cyl.3
Daewoo	Matiz	Engine Petrol	B10S 1,0 EURO III	Live Parameters	43 Segment learn cyl.4
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	1 Engine temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	2 Intake air temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	3 Throttle position
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	4 Battery voltage
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	5 Vehicle speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	6 Engine speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	7 Barometric pressure
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	8 MAP sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	9 MAF (Mass Air Flow)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	10 Injection start
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	11 Injection time
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	12 Residual fuel adjust
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	13 Gear ratio (M/T)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	14 Gear ratio(AT)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	15 Canister purge valve, duty cycle
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	16 Fuel tank level
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	17 Evaporator temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	18 P/N switch
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	19 Engine status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	20 Fuel pump relay
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	21 Engine full load
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	22 Idle switch
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	23 AC relay
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	24 Cooling fan low speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	25 Cooling fan high speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	26 Idle speed actuator duty cycle
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	27 Desired idle speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	28 Long term fuel part load
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	29 Long term fuel trim at idle
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	30 Short term fuel trim
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	31 Knock sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	32 Octane of fuel
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	33 Closed loop fuel control
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	34 Upstream O2 sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	35 Actual IACV(Idle air control valve) step
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO II	Live Parameters	36 Desired IACV (Idle air control valve) step
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	1 Engine temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	2 Intake air temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	3 Throttle position
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	4 Battery voltage
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	5 Vehicle speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	6 Engine speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	7 Barometric pressure
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	8 MAP sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	9 MAF (Mass Air Flow)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	10 Injection start

Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	11 Injection time
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	12 Residual fuel adjust
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	13 Gear ratio (M/T)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	14 Gear ratio(A/T)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	15 Canister purge valve, duty cycle
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	16 EGR command
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	17 Fuel tank level
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	18 Evaporator temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	19 P/N switch
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	20 Engine status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	21 Fuel pump relay
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	22 Engine full load
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	23 Idle switch
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	24 AC relay
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	25 Cooling fan low speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	26 Cooling fan high speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	27 EGR valve status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	28 Motorized throttle idle actuator duty
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	29 Desired idle speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	30 Long term fuel part load
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	31 Long term fuel trim at idle
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	32 Short term fuel trim
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	33 Knock sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	34 Octane of fuel
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	35 Wheel speed (hall)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	36 Wheel speed (magnetic)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	37 Total distance last time DTC was stored
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	38 Closed loop fuel control
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	39 Upstream O2 sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	40 Downstream O2 sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	41 Closed loop fuel (adaptation factor)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	42 Actual IACV(Idle air control valve) step
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	43 Desired IACV (Idle air control valve) step
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	44 Segment learn status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	45 Segment learn cyl.1
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	46 Segment learn cyl.2
Daewoo	Matiz	Engine Petrol	F8CV 0,8 EURO III & IV	Live Parameters	47 Segment learn cyl.3
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	1 Engine speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	1 Engine speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	2 MAP sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	2 MAP sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	3 Throttle position sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	3 Throttle position sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	4 Coolant temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	4 Coolant temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	5 Intake air temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	5 Intake air temperature
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	6 Barometric pressure
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	6 Barometric pressure
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	7 Injection time
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	7 Injection time
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	8 Injection start
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	8 Injection start
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	9 Battery voltage
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	9 Battery voltage
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	10 Canister purge valve, duty cycle
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	10 Canister purge valve, duty cycle
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	11 EGR command
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	11 EGR command

Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	12 Motorized throttle idle actuator, actual value
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	12 Vehicle speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	13 Motorized throttle idle actuator, desired value
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	13 Engine status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	14 Vehicle speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	14 Desired idle speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	15 A/C pressure
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	15 O2 sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	16 Gear ratio (M/T)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	16 O2 sensor heating
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	17 Gear ratio(A/T)
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	17 Idle speed actuator duty cycle
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	18 Engine status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	18 Knock sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	19 Desired idle speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	19 EGR valve status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	20 O2 sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	20 Long term fuel trim
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	21 O2 sensor heating
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	21 Short term fuel trim
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	22 Motorized throttle idle actuator duty
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	22 Fuel pump status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	23 Knock sensor
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	23 Engine full load
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	24 EGR valve status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	24 Idle switch
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	25 Long term fuel trim
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	25 AC relay
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	26 Short term fuel trim
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	26 Cooling fan low speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	27 Fuel pump status
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	27 Cooling fan high speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	28 Engine full load
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	29 Idle switch
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	30 AC relay
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	31 Cooling fan low speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	32 Cooling fan high speed
Daewoo	Matiz	Engine Petrol	F8CV 0,8 General	Live Parameters	33 P/N switch(A/T only)