

Manufacturer	Model	System	Ecu name	Ecu name2	Feature	Feature ID	Detail
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		ECU Information	1	Software number
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		ECU Information	2	Software version number
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		ECU Information	3	Programming date
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	1	Fuel temperature (raw value)
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	2	Fuel temperature
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	3	Boost pressure 1 raw
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	4	Boost pressure 2 raw
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	5	Boost pressure
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	6	Accelerator pedal position 1
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	7	Accelerator pedal position 2
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	8	Accelerator pedal position
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	9	Rail pressure (raw value)
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	10	Rail pressure
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	11	Atmospheric pressure (raw value)
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	12	Atmospheric pressure
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	13	Linearised coolant temperature
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	14	Coolant temperature sensor
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	15	Air temperature linearised
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	16	Air temperature
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	17	Sensor supply voltage linearised (Vext1)
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	18	Sensor supply voltage linearised (Vext2)
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	19	Voltage alimentation auxiliary supply
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	20	Vehicle speed
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	21	Pre-crank
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	22	Gearbox ratio
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	23	Air conditioning pressure raw
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	24	Cruise control, On/Off-switch
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	25	EGR valve position raw
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	26	EGR valve position
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	27	Inlet throttle position raw
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	28	Throttle position
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	29	Turbo valve position
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	30	FAP differential pressure raw
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	31	DPF (Diesel Particulate Filter) Differential Pressure
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	32	Exhaust temperature before catalyst
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	33	After catalyst temperature raw
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	34	Temperature after catalyst
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	35	Exhaust gas temperature
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	36	Diesel particulate filter DPF differential pressure - Clean filter
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	37	Fuel supply
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	38	Engine speed
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	39	Engine torque
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	40	Desired boost pressure
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	41	Rail pressure
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	42	Mass air flow sensor
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	43	Turbo actuator drive
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	44	EGR valve drive
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	45	Inlet air throttle drive
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	46	EGR-valve demand
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	47	Fan 1
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	48	Fan 2
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3		Live Parameters	49	Distant pilot injection timing

SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	50	Near pilot injection timing
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	51	Main injection timing demand
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	52	Near post injection timing
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	53	Distant post injection timing
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	54	Distant pilot injection quantity
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	55	Near pilot injection quantity
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	56	Near post injection quantity
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	57	Distant post injection quantity
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	58	Main fuel demand
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	59	IMV current
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	60	Idle speed
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	61	MDP Minimum Drive Pulse Cylinder 1
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	62	MDP Minimum Drive Pulse Cylinder 3
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	63	MDP Minimum Drive Pulse Cylinder 4
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	64	MDP Minimum Drive Pulse Cylinder 2
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	65	Engine state
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	66	Passive anti-theft system enable status
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	67	MDP number of updates - cylinder 1
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	68	MDP number of updates - cylinder 3
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	69	MDP number of updates - cylinder 4
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	70	MDP number of updates - cylinder 2
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	71	Diesel particulate filter DPF percentage of soot load
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	72	Soot mass
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	73	Diesel particulate filter DPF pressure drop due to excessive soot
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	74	Clutch switch
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	75	Brake switch
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	76	Brake safety switch
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	77	Brake pedal
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	78	Air conditioning requested
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	79	HSD 1 voltage
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	80	HSD 2 voltage
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	81	AC output
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	82	ECU relay state
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	83	Glow plug command requested
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	84	Additional heater 1
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	85	Additional heater 2
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	86	Cruise control switch; OFF
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	87	Cruise control (switches released)
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	88	Set cruise acceleration (+)
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	89	Cruise control deceleration switch
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	90	Cruise control switch, resume
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	91	Glow plug lamp
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	92	Check engine lamp
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	93	Fuel filter water lamp
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	94	Immobilizer lamp
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	95	FAP Regeneration
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	96	Programming date
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	97	Tool signature
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	98	Number of reprogramming
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	99	Individual injector correction C3I cylinder 1
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	100	Individual injector correction C3I cylinder 2
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	101	Individual injector correction C3I cylinder 3
SsangYong	Actyon	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	102	Individual injector correction C3I cylinder 4

SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	ECU Information	1 Software number
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	ECU Information	2 Software version number
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	ECU Information	3 Programming date
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	1 Fuel temperature (raw value)
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	2 Fuel temperature
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	3 Boost pressure 1 raw
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	4 Boost pressure 2 raw
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	5 Boost pressure
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	6 Accelerator pedal position 1
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	7 Accelerator pedal position 2
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	8 Accelerator pedal position
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	9 Rail pressure (raw value)
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	10 Rail pressure
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	11 Atmospheric pressure (raw value)
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	12 Atmospheric pressure
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	13 Linearised coolant temperature
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	14 Coolant temperature sensor
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	15 Air temperature linearised
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	16 Air temperature
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	17 Sensor supply voltage linearised (Vext1)
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	18 Sensor supply voltage linearised (Vext2)
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	19 Voltage alimentation auxiliary supply
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	20 Vehicle speed
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	21 Pre-crank
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	22 Gearbox ratio
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	23 Air conditioning pressure raw
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	24 Cruise control, On/Off-switch
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	25 EGR valve position raw
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	26 EGR valve position
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	27 Inlet throttle position raw
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	28 Throttle position
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	29 Turbo valve position
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	30 FAP differential pressure raw
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	31 DPF (Diesel Particulate Filter) Differential Pressure
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	32 Exhaust temperature before catalyst
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	33 After catalyst temperature raw
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	34 Temperature after catalyst
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	35 Exhaust gas temperature
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	36 Diesel particulate filter DPF differential pressure - Clean filter
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	37 Fuel supply
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	38 Engine speed
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	39 Engine torque
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	40 Desired boost pressure
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	41 Rail pressure
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	42 Mass air flow sensor
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	43 Turbo actuator drive
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	44 EGR valve drive
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	45 Inlet air throttle drive
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	46 EGR-valve demand
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	47 Fan 1
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	48 Fan 2
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	49 Distant pilot injection timing
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	50 Near pilot injection timing

SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	51 Main injection timing demand
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	52 Near post injection timing
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	53 Distant post injection timing
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	54 Distant pilot injection quantity
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	55 Near pilot injection quantity
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	56 Near post injection quantity
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	57 Distant post injection quantity
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	58 Main fuel demand
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	59 IMV current
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	60 Idle speed
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	61 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	62 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	63 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	64 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	65 Engine state
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	66 Passive anti-theft system enable status
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	67 MDP number of updates - cylinder 1
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	68 MDP number of updates - cylinder 3
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	69 MDP number of updates - cylinder 4
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	70 MDP number of updates - cylinder 2
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	71 Diesel particulate filter DPF percentage of soot load
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	72 Soot mass
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	73 Diesel particulate filter DPF pressure drop due to excessive soot
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	74 Clutch switch
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	75 Brake switch
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	76 Brake safety switch
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	77 Brake pedal
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	78 Air conditioning requested
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	79 HSD 1 voltage
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	80 HSD 2 voltage
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	81 AC output
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	82 ECU relay state
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	83 Glow plug command requested
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	84 Additional heater 1
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	85 Additional heater 2
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	86 Cruise control switch; OFF
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	87 Cruise control (switches released)
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	88 Set cruise acceleration (+)
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	89 Cruise control deceleration switch
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	90 Cruise control switch, resume
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	91 Glow plug lamp
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	92 Check engine lamp
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	93 Fuel filter water lamp
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	94 Immobilizer lamp
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	95 FAP Regeneration
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	96 Programming date
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	97 Tool signature
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	98 Number of reprogramming
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	99 Individual injector correction C3I cylinder 1
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	100 Individual injector correction C3I cylinder 2
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	101 Individual injector correction C3I cylinder 3
SsangYong	Kyron	Engine Diesel	D20DT 2,0 DCM 3.1 EURO 3	Live Parameters	102 Individual injector correction C3I cylinder 4
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	1 Software number

SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	2 Software version number
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	3 Programming date
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	1 Fuel temperature (raw value)
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	2 Fuel temperature
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	3 Boost pressure 1 raw
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	4 Boost pressure 2 raw
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	5 Boost pressure
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	6 Accelerator pedal position 1
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	7 Accelerator pedal position 2
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	8 Accelerator pedal position
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	9 Rail pressure (raw value)
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	10 Rail pressure
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	11 Atmospheric pressure (raw value)
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	12 Atmospheric pressure
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	13 Linearised coolant temperature
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	14 Coolant temperature sensor
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	15 Air temperature linearised
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	16 Air temperature
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	17 Sensor supply voltage linearised (Vext1)
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	18 Sensor supply voltage linearised (Vext2)
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	19 Voltage alimentation auxiliary supply
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	20 Battery voltage
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	21 Mass air flow sensor
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	22 Vehicle speed
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	23 Pre-crank
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	24 Gearbox ratio
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	25 Engine block accelerometer noise level 0
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	26 Engine block accelerometer noise level 1
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	27 Mileage
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	28 Air conditioning pressure raw
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	29 Air conditioning pressure
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	30 Cruise control, On/Off-switch
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	31 EGR valve position raw
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	32 EGR valve position
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	33 Inlet throttle position raw
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	34 Throttle position
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	35 Turbo valve position
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	36 Fuel supply
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	37 Engine speed
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	38 Engine torque
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	39 Desired boost pressure
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	40 Rail pressure
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	41 Turbo actuator drive
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	42 EGR valve drive
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	43 Inlet air throttle drive
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	44 EGR-valve demand
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	45 Fan 1
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	46 Fan 2
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	47 Distant pilot injection timing
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	48 Near pilot injection timing
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	49 Main injection timing demand
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	50 Near post injection timing
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	51 Distant post injection timing

SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	52 Distant pilot injection quantity
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	53 Near pilot injection quantity
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	54 Near post injection quantity
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	55 Distant post injection quantity
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	56 Main fuel demand
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	57 Cylinder balancing offset cylinder 1
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	58 Cylinder balancing offset cylinder 2
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	59 Cylinder balancing offset cylinder 4
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	60 Cylinder balancing offset cylinder 5
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	61 Cylinder balancing offset cylinder 3
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	62 IMV current
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	63 Idle speed
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	64 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	65 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	66 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	67 MDP Cylinder 5
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	68 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	69 Engine state
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	70 Passive anti-theft system enable status
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	71 MDP number of updates - cylinder 1
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	72 MDP number of updates - cylinder 2
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	73 MDP number of updates - cylinder 4
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	74 MDP number of updates cylinder 5
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	75 MDP number of updates - cylinder 3
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	76 Clutch switch
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	77 Brake switch
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	78 Brake safety switch
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	79 Brake pedal
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	80 Air conditioning requested
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	81 HSD 1 voltage
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	82 HSD 2 voltage
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	83 AC output
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	84 ECU relay state
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	85 Glow plug command requested
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	86 Additional heater 1
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	87 Additional heater 2
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	88 Cruise control switch; OFF
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	89 Cruise control (switches released)
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	90 Set cruise acceleration (+)
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	91 Cruise control deceleration switch
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	92 Cruise control switch, resume
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	93 Rear blower input
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	94 Glow plug lamp
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	95 Check engine lamp
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	96 Fuel filter water lamp
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	97 Immobilizer lamp
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	98 Programming date
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	99 Tool signature
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	100 Number of reprogramming
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	101 Individual injector correction C3I cylinder 1
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	102 Individual injector correction C3I cylinder 2
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	103 Individual injector correction C3I cylinder 3
SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	104 Individual injector correction C3I cylinder 4

SsangYong	Kyron	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	105 Individual injector correction C3I cylinder 5
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	1 Software number
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	2 Software version number
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	3 Programming date
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	1 Fuel temperature (raw value)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	2 Fuel temperature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	3 Boost pressure 1 raw
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	4 Boost pressure 2 raw
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	5 Boost pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	6 Accelerator pedal position 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	7 Accelerator pedal position 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	8 Accelerator pedal position
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	9 Rail pressure (raw value)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	10 Rail pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	11 Atmospheric pressure (raw value)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	12 Atmospheric pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	13 Linearised coolant temperature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	14 Coolant temperature sensor
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	15 Air temperature linearised
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	16 Air temperature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	17 Sensor supply voltage linearised (Vext1)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	18 Sensor supply voltage linearised (Vext2)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	19 Voltage alimentation auxiliary supply
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	20 Battery voltage
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	21 Mass air flow sensor
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	22 Vehicle speed
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	23 Pre-crank
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	24 Gearbox ratio
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	25 Engine block accelerometer noise level 0
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	26 Engine block accelerometer noise level 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	27 Mileage
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	28 Air conditioning pressure raw
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	29 Air conditioning pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	30 Cruise control, On/Off-switch
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	31 EGR valve position raw
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	32 EGR valve position
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	33 Inlet throttle position raw
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	34 Throttle position
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	35 Turbo valve position
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	36 Fuel supply
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	37 Engine speed
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	38 Engine torque
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	39 Desired boost pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	40 Rail pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	41 Turbo actuator drive
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	42 EGR valve drive
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	43 Inlet air throttle drive
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	44 EGR-valve demand
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	45 Fan 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	46 Fan 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	47 Distant pilot injection timing
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	48 Near pilot injection timing
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	49 Main injection timing demand

SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	50	Near post injection timing
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	51	Distant post injection timing
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	52	Distant pilot injection quantity
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	53	Near pilot injection quantity
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	54	Near post injection quantity
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	55	Distant post injection quantity
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	56	Main fuel demand
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	57	Cylinder balancing offset cylinder 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	58	Cylinder balancing offset cylinder 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	59	Cylinder balancing offset cylinder 4
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	60	Cylinder balancing offset cylinder 5
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	61	Cylinder balancing offset cylinder 3
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	62	IMV current
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	63	Idle speed
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	64	MDP Minimum Drive Pulse Cylinder 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	65	MDP Minimum Drive Pulse Cylinder 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	66	MDP Minimum Drive Pulse Cylinder 4
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	67	MDP Cylinder 5
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	68	MDP Minimum Drive Pulse Cylinder 3
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	69	Engine state
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	70	Passive anti-theft system enable status
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	71	MDP number of updates - cylinder 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	72	MDP number of updates - cylinder 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	73	MDP number of updates - cylinder 4
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	74	MDP number of updates cylinder 5
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	75	MDP number of updates - cylinder 3
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	76	Clutch switch
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	77	Brake switch
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	78	Brake safety switch
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	79	Brake pedal
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	80	Air conditioning requested
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	81	HSD 1 voltage
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	82	HSD 2 voltage
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	83	AC output
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	84	ECU relay state
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	85	Glow plug command requested
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	86	Additional heater 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	87	Additional heater 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	88	Cruise control switch; OFF
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	89	Cruise control (switches released)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	90	Set cruise acceleration (+)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	91	Cruise control deceleration switch
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	92	Cruise control switch, resume
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	93	Rear blower input
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	94	Glow plug lamp
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	95	Check engine lamp
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	96	Fuel filter water lamp
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	97	Immobilizer lamp
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	98	Programming date
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	99	Tool signature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	100	Number of reprogramming
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	101	Individual injector correction C3I cylinder 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	102	Individual injector correction C3I cylinder 2

SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	103 Individual injector correction C3I cylinder 3
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	104 Individual injector correction C3I cylinder 4
SsangYong	Rexton	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	105 Individual injector correction C3I cylinder 5
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	ECU Information	1 Software number
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	ECU Information	2 Software version number
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	ECU Information	3 Programming date
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	1 Fuel temperature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	2 Boost pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	3 Accelerator pedal position 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	4 Accelerator pedal position 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	5 Accelerator pedal
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	6 Rail pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	7 Atmospheric pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	8 Coolant temperature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	9 Air temperature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	10 Battery voltage
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	11 Air mass
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	12 Vehicle speed
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	13 Ignition on
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	14 Gearbox ratio
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	15 Battery voltage
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	16 Accelerator pedal position
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	17 Fuel delivery control valve
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	18 Engine speed
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	19 Engine torque
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	20 Coolant temperature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	21 Air temperature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	22 Boost pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	23 Rail pressure
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	24 Air mass
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	25 Variable geometry turbocharger (VGT) actuator
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	26 EGR valve
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	27 EGR throttle position sensor
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	28 EGR
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	29 Fan 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	30 Fan 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	31 Pilot injection timing demand
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	32 Main injection timing demand
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	33 Pilot fuel demand
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	34 Main fuel demand
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	35 Cylinder balancing offset cylinder 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	36 Cylinder balancing offset cylinder 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	37 Cylinder balancing offset cylinder 4
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	38 Cylinder balancing offset cylinder 5
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	39 Cylinder balancing offset cylinder 3
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	40 IMV drive (PWM)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	41 Target idle speed
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	42 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	43 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	44 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	45 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	46 MDP Minimum Drive Pulse Cylinder 5
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	47 Engine state

SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	48 Anti-theft immobilizer
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	49 Battery voltage
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	50 Clutch switch
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	51 Brake switch
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	52 Brake safety switch
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	53 Brake pedal
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	54 Air conditioning requested
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	55 AC requested
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	56 5V sensor supply.1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	57 5V sensor supply,2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	58 AC output
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	59 ECU relay state
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	60 Glow status
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	61 Additional heater 1 request
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	62 Additional heater 2 request
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	63 Cruise control switch; OFF
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	64 Cruise control safety contact
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	65 Set cruise acceleration (+)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	66 Set cruise deceleration (-)
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	67 Cruise control switch, resume
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	68 ABD input status
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	69 Rear blower input
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	70 Glow plug lamp
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	71 Check engine lamp
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	72 Fuel filter water lamp
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	73 Programming date
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	74 Tool signature
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	75 Programmed
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	76 Individual injector correction, C2I cylinder 1
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	77 Individual injector correction, C2I cylinder 2
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	78 Individual injector correction, C2I cylinder 3
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	79 Individual injector correction, C2I cylinder 4
SsangYong	Rexton	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	80 Individual injector correction, C2I cylinder 5
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	1 Software number
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	2 Software version number
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	3 Programming date
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	1 Individual injector correction C3I cylinder 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	2 Individual injector correction C3I cylinder 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	3 Individual injector correction C3I cylinder 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	4 Individual injector correction C3I cylinder 4
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	5 Individual injector correction C3I cylinder 5
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	6 Fuel temperature (raw value)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	7 Fuel temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	8 Boost pressure 1 raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	9 Boost pressure 2 raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	10 Boost pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	11 Accelerator pedal position 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	12 Accelerator pedal position 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	13 Accelerator pedal position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	14 Rail pressure (raw value)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	15 Rail pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	16 Atmospheric pressure (raw value)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	17 Atmospheric pressure

SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	18 Linearised coolant temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	19 Coolant temperature sensor
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	20 Air temperature linearised
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	21 Air temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	22 Sensor supply voltage linearised (Vext1)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	23 Sensor supply voltage linearised (Vext2)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	24 Voltage alimentation auxiliary supply
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	25 Battery voltage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	26 Mass air flow sensor (raw value)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	27 Mass air flow sensor
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	28 Vehicle speed
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	29 Pre-crank
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	30 Gearbox ratio
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	31 Engine block accelerometer noise level 0
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	32 Engine block accelerometer noise level 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	33 Mileage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	34 Air conditioning pressure raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	35 Air conditioning pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	36 Cruise control, On/Off-switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	37 EGR valve position raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	38 EGR valve position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	39 Inlet throttle position raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	40 Throttle position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	41 Turbo valve position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	42 FAP differential pressure raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	43 DPF (Diesel Particulate Filter) Differential Pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	44 Estimated exhaust gas temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	45 Exhaust temperature before catalyst
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	46 After catalyst temperature raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	47 Temperature after catalyst
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	48 Exhaust gas temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	49 Kilometre counter
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	50 Estimated before catalyst temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	51 Diesel particulate filter DPF differential pressure - Clean filter
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	52 Fuel level
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	53 Battery voltage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	54 Accelerator pedal position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	55 Fuel supply
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	56 Engine speed
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	57 Engine torque
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	58 Coolant temperature sensor
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	59 Air temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	60 Boost pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	61 Desired boost pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	62 Rail pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	63 Mass air flow sensor
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	64 Turbo actuator drive
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	65 EGR valve drive
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	66 Inlet air throttle drive
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	67 Air mass flow demand
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	68 Fan 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	69 Fan 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	70 Distant pilot injection timing

SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	71 Near pilot injection timing
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	72 Main injection timing demand
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	73 Near post injection timing
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	74 Distant post injection timing
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	75 Distant pilot injection quantity
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	76 Near pilot injection quantity
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	77 Near post injection quantity
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	78 Distant post injection quantity
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	79 Main fuel demand
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	80 Cylinder balancing offset cylinder 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	81 Cylinder balancing offset cylinder 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	82 Cylinder balancing offset cylinder 4
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	83 Cylinder balancing offset cylinder 5
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	84 Cylinder balancing offset cylinder 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	85 IMV current
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	86 Idle speed
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	87 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	88 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	89 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	90 MDP Cylinder 5
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	91 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	92 Engine state
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	93 Passive anti-theft system enable status
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	94 MDP number of updates - cylinder 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	95 MDP number of updates - cylinder 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	96 MDP number of updates - cylinder 4
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	97 MDP number of updates cylinder 5
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	98 MDP number of updates - cylinder 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	99 Diesel particulate filter DPF percentage of soot load
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	100 Soot mass
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	101 Diesel particulate filter DPF pressure drop due to excessive soot
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	102 Battery voltage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	103 Clutch switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	104 Brake switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	105 Brake safety switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	106 Brake pedal
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	107 Air conditioning requested
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	108 5V sensors supply nr 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	109 5V sensors supply nr 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	110 5V sensors supply nr 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	111 HSD 1 voltage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	112 HSD 2 voltage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	113 AC output
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	114 ECU relay state
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	115 Glow plug command requested
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	116 Additional heater 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	117 Additional heater 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	118 Cruise control switch; OFF
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	119 Cruise control (switches released)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	120 Set cruise acceleration (+)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	121 Cruise control deceleration switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	122 Cruise control switch, resume
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	123 Rear blower input

SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	124 Glow plug lamp
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	125 Check engine lamp
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	126 Fuel filter water lamp
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	127 Immobilizer lamp
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	128 VLC offset (low speed)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	129 VLC offset (high speed)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	130 Throttle open learning valid
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	131 Open position average learnings
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	132 Throttle closed learning valid
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	133 Closed position average learnings
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	134 Air throttle learnings closed position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	135 Air throttle learnings open position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	1 Software number
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	2 Software version number
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	3 Programming date
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	1 Fuel temperature (raw value)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	2 Fuel temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	3 Boost pressure 1 raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	4 Boost pressure 2 raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	5 Boost pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	6 Accelerator pedal position 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	7 Accelerator pedal position 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	8 Accelerator pedal position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	9 Rail pressure (raw value)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	10 Rail pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	11 Atmospheric pressure (raw value)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	12 Atmospheric pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	13 Linearised coolant temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	14 Coolant temperature sensor
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	15 Air temperature linearised
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	16 Air temperature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	17 Sensor supply voltage linearised (Vext1)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	18 Sensor supply voltage linearised (Vext2)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	19 Voltage alimentation auxiliary supply
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	20 Battery voltage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	21 Mass air flow sensor
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	22 Vehicle speed
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	23 Pre-crank
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	24 Gearbox ratio
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	25 Engine block accelerometer noise level 0
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	26 Engine block accelerometer noise level 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	27 Mileage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	28 Air conditioning pressure raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	29 Air conditioning pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	30 Cruise control, On/Off-switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	31 EGR valve position raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	32 EGR valve position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	33 Inlet throttle position raw
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	34 Throttle position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	35 Turbo valve position
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	36 Fuel supply
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	37 Engine speed
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	38 Engine torque

SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	39 Desired boost pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	40 Rail pressure
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	41 Turbo actuator drive
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	42 EGR valve drive
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	43 Inlet air throttle drive
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	44 EGR-valve demand
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	45 Fan 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	46 Fan 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	47 Distant pilot injection timing
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	48 Near pilot injection timing
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	49 Main injection timing demand
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	50 Near post injection timing
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	51 Distant post injection timing
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	52 Distant pilot injection quantity
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	53 Near pilot injection quantity
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	54 Near post injection quantity
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	55 Distant post injection quantity
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	56 Main fuel demand
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	57 Cylinder balancing offset cylinder 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	58 Cylinder balancing offset cylinder 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	59 Cylinder balancing offset cylinder 4
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	60 Cylinder balancing offset cylinder 5
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	61 Cylinder balancing offset cylinder 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	62 IMV current
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	63 Idle speed
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	64 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	65 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	66 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	67 MDP Cylinder 5
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	68 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	69 Engine state
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	70 Passive anti-theft system enable status
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	71 MDP number of updates - cylinder 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	72 MDP number of updates - cylinder 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	73 MDP number of updates - cylinder 4
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	74 MDP number of updates cylinder 5
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	75 MDP number of updates - cylinder 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	76 Clutch switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	77 Brake switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	78 Brake safety switch
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	79 Brake pedal
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	80 Air conditioning requested
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	81 HSD 1 voltage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	82 HSD 2 voltage
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	83 AC output
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	84 ECU relay state
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	85 Glow plug command requested
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	86 Additional heater 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	87 Additional heater 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	88 Cruise control switch; OFF
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	89 Cruise control (switches released)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	90 Set cruise acceleration (+)
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	91 Cruise control deceleration switch

SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	92 Cruise control switch, resume
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	93 Rear blower input
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	94 Glow plug lamp
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	95 Check engine lamp
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	96 Fuel filter water lamp
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	97 Immobilizer lamp
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	98 Programming date
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	99 Tool signature
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	100 Number of reprogramming
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	101 Individual injector correction C3I cylinder 1
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	102 Individual injector correction C3I cylinder 2
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	103 Individual injector correction C3I cylinder 3
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	104 Individual injector correction C3I cylinder 4
SsangYong	Rexton	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	105 Individual injector correction C3I cylinder 5
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	1 Software number
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	2 Software version number
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	ECU Information	3 Programming date
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	1 Fuel temperature (raw value)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	2 Fuel temperature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	3 Boost pressure 1 raw
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	4 Boost pressure 2 raw
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	5 Boost pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	6 Accelerator pedal position 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	7 Accelerator pedal position 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	8 Accelerator pedal position
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	9 Rail pressure (raw value)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	10 Rail pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	11 Atmospheric pressure (raw value)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	12 Atmospheric pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	13 Linearised coolant temperature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	14 Coolant temperature sensor
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	15 Air temperature linearised
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	16 Air temperature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	17 Sensor supply voltage linearised (Vext1)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	18 Sensor supply voltage linearised (Vext2)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	19 Voltage alimentation auxiliary supply
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	20 Battery voltage
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	21 Mass air flow sensor
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	22 Vehicle speed
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	23 Pre-crank
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	24 Gearbox ratio
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	25 Engine block accelerometer noise level 0
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	26 Engine block accelerometer noise level 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	27 Mileage
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	28 Air conditioning pressure raw
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	29 Air conditioning pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	30 Cruise control, On/Off-switch
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	31 EGR valve position raw
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	32 EGR valve position
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	33 Inlet throttle position raw
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	34 Throttle position
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	35 Turbo valve position
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	36 Fuel supply

SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	37 Engine speed
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	38 Engine torque
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	39 Desired boost pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	40 Rail pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	41 Turbo actuator drive
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	42 EGR valve drive
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	43 Inlet air throttle drive
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	44 EGR-valve demand
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	45 Fan 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	46 Fan 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	47 Distant pilot injection timing
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	48 Near pilot injection timing
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	49 Main injection timing demand
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	50 Near post injection timing
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	51 Distant post injection timing
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	52 Distant pilot injection quantity
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	53 Near pilot injection quantity
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	54 Near post injection quantity
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	55 Distant post injection quantity
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	56 Main fuel demand
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	57 Cylinder balancing offset cylinder 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	58 Cylinder balancing offset cylinder 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	59 Cylinder balancing offset cylinder 4
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	60 Cylinder balancing offset cylinder 5
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	61 Cylinder balancing offset cylinder 3
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	62 IMV current
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	63 Idle speed
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	64 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	65 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	66 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	67 MDP Cylinder 5
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	68 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	69 Engine state
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	70 Passive anti-theft system enable status
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	71 MDP number of updates - cylinder 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	72 MDP number of updates - cylinder 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	73 MDP number of updates - cylinder 4
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	74 MDP number of updates cylinder 5
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	75 MDP number of updates - cylinder 3
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	76 Clutch switch
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	77 Brake switch
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	78 Brake safety switch
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	79 Brake pedal
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	80 Air conditioning requested
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	81 HSD 1 voltage
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	82 HSD 2 voltage
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	83 AC output
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	84 ECU relay state
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	85 Glow plug command requested
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	86 Additional heater 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	87 Additional heater 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	88 Cruise control switch; OFF
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	89 Cruise control (switches released)

SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	90 Set cruise acceleration (+)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	91 Cruise control deceleration switch
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	92 Cruise control switch, resume
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	93 Rear blower input
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	94 Glow plug lamp
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	95 Check engine lamp
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	96 Fuel filter water lamp
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	97 Immobilizer lamp
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	98 Programming date
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	99 Tool signature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	100 Number of reprogramming
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	101 Individual injector correction C3I cylinder 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	102 Individual injector correction C3I cylinder 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	103 Individual injector correction C3I cylinder 3
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	104 Individual injector correction C3I cylinder 4
SsangYong	Rodius	Engine Diesel	D27DT 2,7 DCM 3.2 EURO 4	Live Parameters	105 Individual injector correction C3I cylinder 5
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	ECU Information	1 Software number
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	ECU Information	2 Software version number
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	ECU Information	3 Programming date
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	1 Fuel temperature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	2 Boost pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	3 Accelerator pedal position 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	4 Accelerator pedal position 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	5 Accelerator pedal
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	6 Rail pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	7 Atmospheric pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	8 Coolant temperature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	9 Air temperature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	10 Battery voltage
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	11 Air mass
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	12 Vehicle speed
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	13 Ignition on
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	14 Gearbox ratio
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	15 Battery voltage
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	16 Accelerator pedal position
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	17 Fuel delivery control valve
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	18 Engine speed
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	19 Engine torque
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	20 Coolant temperature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	21 Air temperature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	22 Boost pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	23 Rail pressure
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	24 Air mass
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	25 Variable geometry turbocharger (VGT) actuator
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	26 EGR valve
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	27 EGR throttle position sensor
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	28 EGR
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	29 Fan 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	30 Fan 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	31 Pilot injection timing demand
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	32 Main injection timing demand
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	33 Pilot fuel demand
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	34 Main fuel demand

SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	35 Cylinder balancing offset cylinder 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	36 Cylinder balancing offset cylinder 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	37 Cylinder balancing offset cylinder 4
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	38 Cylinder balancing offset cylinder 5
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	39 Cylinder balancing offset cylinder 3
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	40 IMV drive (PWM)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	41 Target idle speed
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	42 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	43 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	44 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	45 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	46 MDP Minimum Drive Pulse Cylinder 5
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	47 Engine state
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	48 Anti-theft immobilizer
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	49 Battery voltage
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	50 Clutch switch
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	51 Brake switch
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	52 Brake safety switch
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	53 Brake pedal
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	54 Air conditioning requested
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	55 AC requested
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	56 5V sensor supply.1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	57 5V sensor supply,2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	58 AC output
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	59 ECU relay state
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	60 Glow status
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	61 Additional heater 1 request
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	62 Additional heater 2 request
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	63 Cruise control switch; OFF
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	64 Cruise control safety contact
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	65 Set cruise acceleration (+)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	66 Set cruise deceleration (-)
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	67 Cruise control switch, resume
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	68 ABD input status
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	69 Rear blower input
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	70 Glow plug lamp
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	71 Check engine lamp
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	72 Fuel filter water lamp
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	73 Programming date
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	74 Tool signature
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	75 Programmed
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	76 Individual injector correction, C2I cylinder 1
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	77 Individual injector correction, C2I cylinder 2
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	78 Individual injector correction, C2I cylinder 3
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	79 Individual injector correction, C2I cylinder 4
SsangYong	Rodius	Engine Diesel	D27DT 2,7 Delphi	Live Parameters	80 Individual injector correction, C2I cylinder 5
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	1 Software number
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	2 Software version number
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	3 Programming date
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	1 Individual injector correction C3I cylinder 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	2 Individual injector correction C3I cylinder 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	3 Individual injector correction C3I cylinder 3
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	4 Individual injector correction C3I cylinder 4

SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	5 Individual injector correction C3I cylinder 5
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	6 Fuel temperature (raw value)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	7 Fuel temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	8 Boost pressure 1 raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	9 Boost pressure 2 raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	10 Boost pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	11 Accelerator pedal position 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	12 Accelerator pedal position 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	13 Accelerator pedal position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	14 Rail pressure (raw value)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	15 Rail pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	16 Atmospheric pressure (raw value)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	17 Atmospheric pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	18 Linearised coolant temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	19 Coolant temperature sensor
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	20 Air temperature linearised
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	21 Air temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	22 Sensor supply voltage linearised (Vext1)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	23 Sensor supply voltage linearised (Vext2)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	24 Voltage alimentation auxiliary supply
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	25 Battery voltage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	26 Mass air flow sensor (raw value)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	27 Mass air flow sensor
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	28 Vehicle speed
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	29 Pre-crank
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	30 Gearbox ratio
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	31 Engine block accelerometer noise level 0
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	32 Engine block accelerometer noise level 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	33 Mileage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	34 Air conditioning pressure raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	35 Air conditioning pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	36 Cruise control, On/Off-switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	37 EGR valve position raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	38 EGR valve position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	39 Inlet throttle position raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	40 Throttle position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	41 Turbo valve position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	42 FAP differential pressure raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	43 DPF (Diesel Particulate Filter) Differential Pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	44 Estimated exhaust gas temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	45 Exhaust temperature before catalyst
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	46 After catalyst temperature raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	47 Temperature after catalyst
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	48 Exhaust gas temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	49 Kilometre counter
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	50 Estimated before catalyst temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	51 Diesel particulate filter DPF differential pressure - Clean filter
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	52 Fuel level
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	53 Battery voltage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	54 Accelerator pedal position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	55 Fuel supply
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	56 Engine speed
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	57 Engine torque

SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	58 Coolant temperature sensor
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	59 Air temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	60 Boost pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	61 Desired boost pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	62 Rail pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	63 Mass air flow sensor
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	64 Turbo actuator drive
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	65 EGR valve drive
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	66 Inlet air throttle drive
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	67 Air mass flow demand
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	68 Fan 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	69 Fan 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	70 Distant pilot injection timing
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	71 Near pilot injection timing
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	72 Main injection timing demand
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	73 Near post injection timing
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	74 Distant post injection timing
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	75 Distant pilot injection quantity
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	76 Near pilot injection quantity
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	77 Near post injection quantity
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	78 Distant post injection quantity
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	79 Main fuel demand
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	80 Cylinder balancing offset cylinder 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	81 Cylinder balancing offset cylinder 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	82 Cylinder balancing offset cylinder 4
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	83 Cylinder balancing offset cylinder 5
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	84 Cylinder balancing offset cylinder 3
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	85 IMV current
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	86 Idle speed
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	87 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	88 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	89 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	90 MDP Cylinder 5
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	91 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	92 Engine state
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	93 Passive anti-theft system enable status
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	94 MDP number of updates - cylinder 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	95 MDP number of updates - cylinder 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	96 MDP number of updates - cylinder 4
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	97 MDP number of updates cylinder 5
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	98 MDP number of updates - cylinder 3
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	99 Diesel particulate filter DPF percentage of soot load
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	100 Soot mass
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	101 Diesel particulate filter DPF pressure drop due to excessive soot
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	102 Battery voltage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	103 Clutch switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	104 Brake switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	105 Brake safety switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	106 Brake pedal
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	107 Air conditioning requested
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	108 5V sensors supply nr 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	109 5V sensors supply nr 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	110 5V sensors supply nr 3

SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	111 HSD 1 voltage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	112 HSD 2 voltage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	113 AC output
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	114 ECU relay state
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	115 Glow plug command requested
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	116 Additional heater 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	117 Additional heater 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	118 Cruise control switch; OFF
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	119 Cruise control (switches released)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	120 Set cruise acceleration (+)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	121 Cruise control deceleration switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	122 Cruise control switch, resume
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	123 Rear blower input
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	124 Glow plug lamp
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	125 Check engine lamp
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	126 Fuel filter water lamp
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	127 Immobilizer lamp
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	128 VLC offset (low speed)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	129 VLC offset (high speed)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	130 Throttle open learning valid
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	131 Open position average learnings
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	132 Throttle closed learning valid
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	133 Closed position average learnings
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	134 Air throttle learnings closed position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	135 Air throttle learnings open position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	1 Software number
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	2 Software version number
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	ECU Information	3 Programming date
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	1 Fuel temperature (raw value)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	2 Fuel temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	3 Boost pressure 1 raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	4 Boost pressure 2 raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	5 Boost pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	6 Accelerator pedal position 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	7 Accelerator pedal position 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	8 Accelerator pedal position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	9 Rail pressure (raw value)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	10 Rail pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	11 Atmospheric pressure (raw value)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	12 Atmospheric pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	13 Linearised coolant temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	14 Coolant temperature sensor
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	15 Air temperature linearised
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	16 Air temperature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	17 Sensor supply voltage linearised (Vext1)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	18 Sensor supply voltage linearised (Vext2)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	19 Voltage alimentation auxiliary supply
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	20 Battery voltage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	21 Mass air flow sensor
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	22 Vehicle speed
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	23 Pre-crank
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	24 Gearbox ratio
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	25 Engine block accelerometer noise level 0

SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	26 Engine block accelerometer noise level 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	27 Mileage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	28 Air conditioning pressure raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	29 Air conditioning pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	30 Cruise control, On/Off-switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	31 EGR valve position raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	32 EGR valve position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	33 Inlet throttle position raw
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	34 Throttle position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	35 Turbo valve position
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	36 Fuel supply
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	37 Engine speed
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	38 Engine torque
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	39 Desired boost pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	40 Rail pressure
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	41 Turbo actuator drive
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	42 EGR valve drive
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	43 Inlet air throttle drive
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	44 EGR-valve demand
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	45 Fan 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	46 Fan 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	47 Distant pilot injection timing
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	48 Near pilot injection timing
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	49 Main injection timing demand
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	50 Near post injection timing
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	51 Distant post injection timing
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	52 Distant pilot injection quantity
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	53 Near pilot injection quantity
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	54 Near post injection quantity
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	55 Distant post injection quantity
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	56 Main fuel demand
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	57 Cylinder balancing offset cylinder 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	58 Cylinder balancing offset cylinder 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	59 Cylinder balancing offset cylinder 4
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	60 Cylinder balancing offset cylinder 5
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	61 Cylinder balancing offset cylinder 3
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	62 IMV current
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	63 Idle speed
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	64 MDP Minimum Drive Pulse Cylinder 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	65 MDP Minimum Drive Pulse Cylinder 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	66 MDP Minimum Drive Pulse Cylinder 4
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	67 MDP Cylinder 5
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	68 MDP Minimum Drive Pulse Cylinder 3
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	69 Engine state
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	70 Passive anti-theft system enable status
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	71 MDP number of updates - cylinder 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	72 MDP number of updates - cylinder 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	73 MDP number of updates - cylinder 4
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	74 MDP number of updates cylinder 5
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	75 MDP number of updates - cylinder 3
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	76 Clutch switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	77 Brake switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	78 Brake safety switch

SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	79 Brake pedal
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	80 Air conditioning requested
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	81 HSD 1 voltage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	82 HSD 2 voltage
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	83 AC output
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	84 ECU relay state
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	85 Glow plug command requested
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	86 Additional heater 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	87 Additional heater 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	88 Cruise control switch; OFF
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	89 Cruise control (switches released)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	90 Set cruise acceleration (+)
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	91 Cruise control deceleration switch
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	92 Cruise control switch, resume
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	93 Rear blower input
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	94 Glow plug lamp
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	95 Check engine lamp
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	96 Fuel filter water lamp
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	97 Immobilizer lamp
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	98 Programming date
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	99 Tool signature
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	100 Number of reprogramming
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	101 Individual injector correction C3I cylinder 1
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	102 Individual injector correction C3I cylinder 2
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	103 Individual injector correction C3I cylinder 3
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	104 Individual injector correction C3I cylinder 4
SsangYong	Rodius	Engine Diesel	D27DTP 2,7 DPF DCM 3.2 EURO 4	Live Parameters	105 Individual injector correction C3I cylinder 5